



STEP 3




- 3. MAKE SURE LOCK PINS EXTEND AND FULLY RETRACT BEFORE PLACING SLIDER IN SERVICE.
- 2. SLIDER MODEL: NEWWAY NSH SLIDES REAR PIN.
- 1. INSTALLATION PROCEDURE FOR KIT 29559-08 AND -09.

												29	
	ER NO.	SYM	REVISIONS					DATE	BY	CHK	APPD	ا يۆر	
TASSY: NEXT	DRAWN: ML DATE: 3/22/20		3/22/2018	HUTCHENS INDUSTRIES, INC.								&	
TOLERANCES UNLESS OTHERWISE SPECIFIED)	JAJ		DATE: 10/4/2018	IIIIX	SPRINGFIELD, MISSOUR								
DECIMAL .X ± .1	APPROVED: RSB		DATE: 10/4/2018	TITLE:	Hutchens Industries								
DECIMAL XXX ± .06 DECIMAL XXX ± .030	MFG APPL: N/A DATE: XX/XX/XX			INSTALLATION PROCEDURE								R	ł
ANGULAR ± 1° HOLES:	ER: 2018044		DATE: 10/5/2018										
.50 DIA AND LESS: ± .007	PROJECT OR FILE REFERENCE NO. PROJ#: 20180400		FOR 29559-08, -09 KIT										
.51 DIA AND GREATER: ± .01 MOVE ALL SHARP BURRS & SHARP	EPR#: 20180400-01										_		
CORNERS THAT MIGHT AFFECT ASSEMBLY, APPEARANCE, OR OPERATION OF OUR PRODUCTS.	D SIZE - 1/2		SHEET 1	OF 2	SIZE:	DRAWING NO.:	wing no.: 29648		REV.	유			
	B SIZE - 1/4				ן ט				3		N		




STEP 5



ASSEMBLE SPECIAL WASHER AND PIN ENGAGEMENT SPRING ONTO LINKAGE ROD AND GUIDE THROUGH THE SPRING CAGE PLATE.

REMOVE THE RETAINER FROM PIN CAGE HOLES STEP 8 HOOK THE END OF THE LINKAGE ROD THROUGH THE CAM. PLACE THE WASHER ON THE LINKAGE ROD ON THE OPPOSITE SIDE OF THE CAM.



3. MAKE SURE LOCK PINS EXTEND AND FULLY RETRACT BEFORE PLACING SLIDER IN SERVICE.

2. SLIDER MODEL: NEWWAY NSH SLIDES REAR PIN.

1. INSTALLATION PROCEDURE FOR KIT 29559-08 AND -09.

NEXT ASSY: NEXT ML 3/22/2018
DE JAJ DATE: 10/4/2018
DED: RSB DATE: 10/4/2018
DATE: 10/4/2018 HUTCHENS INDUSTRIES, INC. SPRINGFIELD, MISSOURI

WELD THE WASHER ON TO THE LINKAGE ROD.

29648

NEXT ASSY: NEXT

TOLERANCES

(UNLESS OTHERWISE SPECIFIED)
DECIMAL X± .10
DECIMAL X± .06
DECIMAL XX ± .06
ANGULAR ± 1°
HOLES:
.50 DIA AND LESS: ± .007
.51 DIA AND GREATER: ± .01
REMOVE ALL SHARP BURRS & SHARP
CORNERS THAT MIGHT AFFECT
ASSEMBLY, APPEARANCE, OR
OPERATION OF OUR PRODUCTS. R: 2018044 DATE: XX/XX/XX PROJECT OR FILE REFERENCE NO. INSTALLATION PROCEDURE FOR 29559-08, -09 KIT PROJ#: 20180400 EPR#: 20180400-01 D SIZE - 1/2 B SIZE - 1/4 SHEET 2 OF 2 D