


STEP 2





COMPRESS THE LOCK PIN AND RETRACTION SPRING.
INSERT A RETAINER (ROD, SCREWDRIVER, ETC.)
THROUGH THE PIN CAGE HOLES.

STEP 4


- 3. MAKE SURE LOCK PINS EXTEND AND FULLY RETRACT BEFORE PLACING SLIDER IN SERVICE.
- 2. SLIDER MODEL: H9851/H9861.
- 1. INSTALLATION PROCEDURE FOR KIT 29573-01 AND -02.


													29	
	ER NO.	SYM			REVISI	ONS			DATE	BY	CHK	APPD	വര	
EXT ASSY: NEXT	DRAWN: ML DATE: 3/22/20		3/22/2018	<del> </del>	П		<b>37</b>	NI T	CHEME	NDUCTO	ILC INC		85	
IOLERANCES	CHECKED:	JAJ	DATE: 10/4/2018	HUTCHENS INDUSTRIES, SPRINGFIELD, MISSOU Hutchens Industries										
(UNLESS OTHERWISE SPECIFIED) DECIMAL .X ± .1	APPROVED:	RSB	DATE: 10/4/2018	TITLE:	cher	ıs ina	lustrie	s						
DECIMAL .XX ± .06 DECIMAL .XXX + .030	MFG APPL:	N/A	DATE: XX/XX/XX		INIC	-ТΛΙ	. A <del>T</del>		٠٠٠.	IDE			REV	
ANGULAR ± 1°	ER: 2018044 DATE: 10/5/2018			INSTALLATION PROCEDURE								. ?		
HOLES: .50 DIA AND LESS: ± .007	PROJECT OR FILE REFERENCE NO. PROJ#: 20180400			FOR 29573-01, -02 KIT										
.51 DIA AND GREATER: ± .01 REMOVE ALL SHARP BURRS & SHARP			80400-01										_	
CORNERS THAT MIGHT AFFECT	П	SIZE		OUEET 4	٥-	2	SIZE:	DRAWING NO.:				REV.	유	
ASSEMBLY, APPEARANCE, OR OPERATION OF OUR PRODUCTS.	B SIZE - 1/4			SHEET	SHEET 1 OF 2 D				29685 -			-	N	





ASSEMBLE SPECIAL WASHER AND PIN ENGAGEMENT SPRING ONTO LINKAGE ROD AND GUIDE THROUGH THE SPRING CAGE PLATE.





3. MAKE SURE LOCK PINS EXTEND AND FULLY RETRACT BEFORE PLACING SLIDER IN SERVICE.

2. SLIDER MODEL: H9851/H9861.

1. INSTALLATION PROCEDURE FOR KIT 29573-01 AND -02.

													29685	
	ER NO.	SYM	REVISIONS						DATE	BY	CHK	APPD	000	
NEXT ASSY: NEX I		ML	DATE: 3/22/2018	K	П	7	27	нит	CHENSI	NDUSTR	DIES INC		35	
(LINI ESS OTHERWISE SPECIFIED)	CHECKED: JAJ DATE: 10/4/2018 D) ADDREVIEW DATE: Hutchens Inclustries													
DECIMAL .X ± .1	RSB 10/4/2018 TITLE:										1			
DECIMAL XXX ± .030		N/A	DATE: XX/XX/XX	XX/XX/XX						OFFILE				
ANGULAR ± 1° HOLES:	ER: 20180	44	DATE: 10/5/2018	INSTALLATION PROCEDURE									REV.	
.50 DIA AND LESS: ± .007			180400	FOR 29573-01, -02 KIT										
.51 DIA AND GREATER: ± .01 REMOVE ALL SHARP BURRS & SHARP		2018	0400-01										0	
CORNERS THAT MIGHT AFFECT ASSEMBLY, APPEARANCE, OR	D	SIZE		SHEET 2	OF	2	SIZE:	DRAWING NO.:		_		REV.	유	
OPERATION OF OUR PRODUCTS.		SIZE		SHEET Z	<b>Z</b> UF		U	2	29685			-	N	